4F8135

Kodak **Li-Ion Rapid Battery Charger Model K8500**

User's Guide

Thank you for purchasing the KODAK Li-Ion Rapid Battery Charger. The battery needs to be charged before using and takes approximately 3 hours or less. The battery can be charged and discharged approximately 300 times. Additional KODAK Li-Ion Batteries are available from dealers of Kodak products, or visit www.kodak.com/go/batteries.

Easy Steps to Charging

- Verify that you are loading a Li-lon rechargeable battery. Do not load other types into the charger.
- 2. Insert the battery into the charger with the +/contacts facing the +/- contact points in the charger.
- 3. Insert the plug that matches your power type then plug the charger into a power outlet.
- 4. Verify that the red charge indicator light on the charger turns on. If the light does not turn on, verify that the battery is inserted correctly.
- 5. Remove the battery and unplug the charger when the red indicator light turns green. Charging takes approximately 3 hours or less.

IMPORTANT SAFETY INSTRUCTIONS— Save These Instructions

- DANGER—TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.
- For connection to a supply not in the U.S.A., use an attachment plug adapter of the proper configuration for the power outlet. This battery charger is intended to be correctly oriented in a vertical or floor mount

CAUTION:

- Charge only compatible Li-lon rechargeable batteries. Other types of batteries may burst causing personal injury and damage.
- Risk of electric shock. Use only in dry locations.
- Do not operate charger if it has been damaged.
- To reduce the risk of electric shock, unplug charger from outlet before attempting any maintenance or cleaning.
- Be sure to use charger with correct voltage: AC 100-240V.

 • Do not insert any objects (such as a screwdriver or
- metal wires) into the charger.
- Do not modify or disassemble.
- If something appears wrong with the charger and/or batteries, disconnect from the electric outlet immediately.
- . Keep out of reach of infants. Children may use only under strict parental supervision.
- Store in a dry, cool place.

Recommended temperature ranges for use:


32°-122° F (0°-50° C) To use (discharge) the

To charge the batteries 32°-95° F (0°-35° C) -4°-86° F (-20°-30° C) To store the batteries

Waste Electrical and Electronic **Equipment Labeling**

In Europe: For human/environmental protection, it is your responsibility to dispose of this equipment at a collection facility established for this purpose

(separate from municipal waste). For more information, contact your retailer, collection facility, or appropriate local authorities; or visit www.kodak.com/go/recycle. (Product weight: 85 g.)



Camera Battery KLIC-8000

Kodak

Made in China for Eastman Kodak Company Rochester, NY 14650 U.S.A.

© Eastman Kodak Company, 2008. MC/MR/TM: Kodak. 4J8135

www.kodak.com/go/accessories

Regulatory Information

FCC compliance and advisory



Kodak Li-Ion Rapid Battery Charger, Model K8500

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will

not occur in a particular installation.

not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and the receiver; 3) connect the equipment to an outlet on a circuit different from that to which the receiver is connected; 4) consult the dealer or an experienced radio/TV technician for additional suggestions.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation.

Canadian DOC statement

DOC Class B compliance—This Class B digital apparatus complies with Canadian ICES-003.

Observation des normes-Class B—Ce périphérique numérique de la classe B est conforme à la norme NMB-003 du Canada.